


# LOTUS FOLDING WALLS AND DOORS PTY LTD

Please follow these instructions for ease of operation and good acoustic performance. See over for hints and problem solving.

Your wall reference No. is: 24591-2

**TAKE CARE!** Ensure footbolts used where indicated.  
Ensure seals raised where indicated.  
Panels are heavy; move firmly but slowly

## INTRODUCTION



**A** – Main panel including Primary Expanda

**B** – Pair of panels including Secondary Expanda and grab ring




**C** – Expanda Sleeve (key + grab handle not shown here)



## WARNING!

1. Always use Room 161 OR 261 to open or close the folding wall.
2. Please **DO NOT** operate this if you have not received any training. Please see your Administrative Officer.

# TO OPEN




WIND DIRECTION	
Primary Expanda:	Counter clockwise to open
Secondary Expanda:	Clockwise to open seal





# TO CLOSE

WIND DIRECTION	
Primary Expanda:	Clockwise to close
Secondary Expanda:	Counter-clockwise to open



## Linked AV feature

1. ONLY PC in Room 161/261 can be used as the main PC to operate the LINKED AV feature
2. Select Linked AV from the Control Panel in Room 162/262 to display on both video projectors

